

Product data sheet

1-gang rocker for switch and push-button



Reference number

SL 590 SW

1-gang rocker

for switch insert ref.-no.: 501 U, 502 U, 503 U, 506 U, 507 U, 501-20 U, 506-20 U, 507-20 U

for push switch insert ref.-no.: 502 TU, 506 TU, 507 TU

for push-button insert ref.-no.: 531 U, 532 U, 533 U, 533-2 U

Spare part:

holder plate ref.-no.: SL 90 HP

Push-switch inserts are recommended because the triggered rocker returns into original position.

Colour:

black

