


# Product data sheet

## Reset button




---

**Reference number**

---

NRS LS 0834 AT WW

---

**Reset button**

screw fixing only, without claws  
without frame

The reset button is installed next to the door in the same room as the pull cord push-button. The assisting personnel can reset the triggered call.

for LS range

Thermoplastic (breakproof) high-gloss

**Colour:**  
white

**Material:**  
thermoplastic

---